

# 12Ft. Deluxe Raised Bed Instructions

*N.B: The illustrations show a Deluxe 14 inch high bed being assembled. The 9 and 21 inch high beds use the same procedure with the appropriate single or triple tier construction.*

**9 INCH HIGH FLAT PACK CONTAINS:**

*4no. 23cm high treated timber side planks. 3no. 23cm high treated timber end planks, 6no. 11 x 11 x 23cm treated timber fixing posts with 14 galvanized brackets . 56 screws.*

**14 INCH HIGH FLAT PACK CONTAINS:**

*8no. 23cm high treated timber side planks. 6no. 23cm high treated timber end planks, 6no. 11 x11 x 36cm treated timber fixing posts with 14 galvanized brackets . 112 screws.*

**21 INCH HIGH FLAT PACK CONTAINS:**

*12no. 23cm high treated timber side planks. 9no. 23cm high treated timber end planks, 6no. 11 x 11 x 54cm treated timber fixing posts with 14 galvanized brackets . 168 screws.*

*All configurations are supplied with mounting brackets and a right angled fixing guide. The fixing guide is used to position the mounting brackets accurately on the corner posts.*

